

Begin by removing the cheekpiece from the chassis. Next, unscrew the two screws that secure the foamy top.



Now, replace the original cheek piece with our 3D printed plate. Then, secure the two screws.



Place the provided two screws into the slots in the Bison Tactical cheekpiece, and the two square nuts in the slots on the underside of the plate.



Thread the screws into the nuts to connect the two pieces. Keep the screw loose to adjust, and tighten them to set it in place. Do not overtighten. Snug is plenty. Now, reinstall the cheekpiece.

